

The information and recommendations set out in this ADHESIVE CHART are for reference only and have been provided to Vinyl Trends Inc by each adhesive manufacturer. Vinyl Trends Inc and its affiliates strongly recommend that you confirm any information taken from this chart with the adhesive manufacturer prior to any installation. As such, neither Vinyl Trends Inc nor any person acting on its behalf may be held responsible for the use which may be made of the information contained herein.

Adhesive	Underlayment to Substrate	Trowel	Wood Floor to Underlayment	Trowel	LVT / Plank to Underlayment	Trowel
<a href="#">APAC 757</a>	●	1/16" sq	●	+		
<a href="#">Bostik Best</a>	●	3/16X5/32" V	●	+		
<a href="#">Bostik EFA</a>	●	3/16X5/32" V	●	+		
<a href="#">DriTac ECO 5200</a>	●	1/16" sq			●	+
<a href="#">DriTac ECO 5500</a>	●	1/16" sq			●	+
<a href="#">DriTac ECO 5700</a>	●	1/16" sq			●	+
<a href="#">DriTac ECO 5900</a>	●	1/16" sq			●	+
<a href="#">DriTac 6200</a>	●	1/16" sq	●	+	●	+
<a href="#">DriTac ECO 6200 GR</a>	●	1/16" sq	●	+	●	+
<a href="#">DriTac 7300 SureBond</a>	●	1/8" sq	●	+		
<a href="#">DriTac 7400 Easy Spread</a>	●	1/8" sq	●	+		
<a href="#">DriTac 7500 Eco-Urethane</a>	●	1/8" sq	●	+		
<a href="#">Dritac 7600 Premium</a>	●	1/8" sq	●	+		
<a href="#">DriTac 7900 Super Grab</a>	●	1/8" sq	●	+		
<a href="#">DriTac 9100</a>	●	1/8" sq	●	+		
<a href="#">DriTac 9500 Ultra</a>	●	1/8" sq	●	+		
<a href="#">Franklin Titebond 811</a>	●	1/8" sq	●	+		
<a href="#">Franklin Titebond 821-Step</a>	●	1/8" sq	●	+		
<a href="#">Franklin Titebond 741</a>	●	1/8" sq	●	+		
<a href="#">Franklin Titebond 771-Step</a>	●	1/8" sq	●	+		
<a href="#">Franklin Titebond 780</a>	●	1/16" sq			●	+
<a href="#">Mapei Ultrabond ECO 975</a>	●	3/16 x 5/32" v	●	+		
<a href="#">Mapei Ultrabond ECO 980</a>	●	3/16 x 5/32" v	●	+		
<a href="#">Mapei Ultrabond ECO 995</a>	●	3/16 x 5/32" v	●	+		
<a href="#">Mapei Ultrabond ECO 360</a>	●	1/32 x 1/16 x 1/32 u			●	+
<a href="#">Royal Signature 4099</a>	●	1/16" sq				
<a href="#">Royal Millennium 2009</a>			●	+		
<a href="#">Royal Millennium 4010</a>			●	+		
<a href="#">Spray-Lock 6500</a>	●	+			●	+

● Recommended by Adhesive Manufacturer

+ Consult Flooring and Adhesive Manufacturers

**This chart is not to be used with Eternity 1 underlayment.**

The information and recommendations set out in this ADHESIVE CHART are for reference only and have been provided to Vinyl Trends Inc by each adhesive manufacturer. Vinyl Trends Inc and its affiliates strongly recommend that you confirm any information taken from this chart with the adhesive manufacturer prior to any installation. As such, neither Vinyl Trends Inc nor any person acting on its behalf may be held responsible for the use which may be made of the information contained herein.

Adhesive	Underlayment to Substrate	Trowel	Wood Floor to Underlayment	Trowel	LVT / Plank to Underlayment	Trowel
<a href="#">Stauf D737</a>	●	3/32 sq	●	+	●	
<a href="#">Stauf AUM 800</a>	●	3/32 sq	●	+	●	
<a href="#">Stauf PIC 850</a>	●	3/32 sq	●	+	●	
<a href="#">Stauf SMP 940</a>	●	3/32 sq	●	+	●	
<a href="#">Stauf PUM 950</a>	●	3/32 sq	●	+	●	
<a href="#">Stauf SMP 960</a>	●	3/32 sq	●	+	●	
<a href="#">Stauf CBR 970</a>	●	3/32 sq	●	+	●	
<a href="#">Taylor 2091</a>	●	1/16" sq			●	+
<a href="#">Taylor MS+ Resilient</a>	●	1/16" sq			●	+
<a href="#">Taylor 2071</a>	●	1/16" sq	●	+		
<a href="#">Taylor MS+ Advance</a>	●	1/16" sq	●	+		

● Recommended by Adhesive Manufacturer

+ Consult Flooring and Adhesive Manufacturers

**This chart is not to be used with Eternity 1 underlayment.**

Make sure that the proper underlayment is being used under the specified finish floor.